

TUNNELWORM

through-zero flanger

OMG! OMG! OMG! OMG! IT'S REAL!!

Thanks for supporting Mr. Black and rockin a TunnelWorm. Its pretty badass.

Every Mr. Black pedal is designed and handmade in the rainy pacific-northwest, Portland, OR to be exact.

TunnelWorm makes that impossible TZF sound, plus other sweet flange tones, and it does it with style and extra mack sauce. FUCK YEAH!!

How to nail that impossible TZF:

- Crack a brewski and put your feet up. This is easy and you need a beer.
- Plug your guitar into the input jack on the right side of the pedal, and your amp into the output jack on the left side of the pedal.
- Set all knobs to minimum and turn the pedal on.
- Turn the ZERO knob up until your signal disappears (HOW THE FUCK DID THAT HAPPEN!?)
- Adjust the WIDTH knob for the desired amount of sweep.
- Set the Rate knob to the speed you like and do the damned thing!!

Features:

- Subtractive through-zero flanging
- ZERO knob (that's just fucking tight)
- True-bypass
- 9V power (2.1mm negative center pin adapter) or internal 9V battery

To replace the 9V battery, grab your trusty philips head screwdriver and remove the four screws holding the backing plate on. The battery sits right below the foot-switch. I think you can handle the rest.

If you haven't already, join the Black List for news, specials, promos and even the occasional hot dog.

Visit: www.mrblack.jackdeville.com to sign up.

Its free. And free is a good color on me.

Controls:

- WIDTH: Adjusts size of sweep
 - Full CCW: Off
 - Full CW: Humungous sweep
- ZERO: Sets the zero point
 - Full CCW: Far away
 - Full CW: Past the zero point
- RATE: C'mon, man.
 - Full CCW: Slow
 - Full CW: Fast
- BYPASS SWITCH: Toggles on/off
 - LED on: **FLANGING BABY!!**
 - LED off: No flanging. :(

Tech stuff:

- Input impedance: ~500K Ω
- Output impedance: ~2K Ω
- Bypass: True-Bypass
- Current draw: <60mA
- Power requirement: 9V adapter or 9V battery